



Photo: SportzFotoz

Jaden Hassan
NZ 600 Supersport

FORMA BOOTS – SIZE CONVERSION CHART

Adult Boot Size Chart

Insole Size	235mm	240mm	245mm	255mm	260mm	265mm	270mm	280mm	285mm	290mm	300mm	305mm	310mm	315mm	320mm	325mm
Euro Size	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50
US Mens			5	6	6½	7½	8½	9	10	10½	11½	12	13	14	14½	15
Kiwi Mens			4	5	5½	6½	7½	8	9	9½	10½	11	12	13	13½	14
Women	5	5½	6	7	7½	8½	9½	10	11	11½	12½	13				

Youth Boot Size Chart

Insole Size	210mm	215mm	220mm	230mm	240mm	245mm	250mm	255mm	260mm
Euro Size	32	33	34	35	36	37	38	39	40
Kiwi Kids	13	1	2	2½	3	4	5	5½	6½

Establish your size by matching the “removable insole” length from your own ride boots to the measurements listed. As a rule the insole measurement will be 15-20mm longer than your foot (around 20-25mm if you have a wide foot). Generally, motorcycle boots are worn one size larger than your everyday shoe size.